



ABLON 35mm FILM TRIMMER TEMPLATE SCALED A4

THIS TEMPLATE IS SET AT 1:1
FULL SCALE WHEN PRINTED TO A4.

THERE SHOULD BE TWO LOCATING
PINS ON ONE SIDE OF THE TOOL
WITH CORRESPONDING HOLES ON
THE OTHER SIDE, SET AT SPROCKET
5 AND 18 FROM THE END OF THE
35MM FILM.

OTHER SPROCKET HOLE LOCATIONS
ARE SHOWN FOR ILLUSTRATIVE
PURPOSES AND DO NOT NEED TO
BE ACCOUNTED FOR IN ANY
WORKING MODEL, ONLY THE
LOCATING PINS AND THEIR
COORDINATES IN RELATION TO THE
MODEL BODY ARE IMPORTANT FOR
THE CORRECT LOCATION OF THE
FILM.

IT IS RECOMMENDED TO CREATE
THIS TOOL USING 2mm NICKEL,
WITH A PINET HINGE TO JOIN THE
TWO SIDES.

PLACE THE FILM WITHIN THE
ABLON, FOLD IT TO CLOSE, AND
MAKE A STEADY CUT ALONG THE
TRIM EDGE WITH A SHARP KNIFE.

