



## FX-UNIVERSAL FIXING BATH

### 5 LITRE CONCENTRATE

#### INSTRUCTIONS FOR USE:

##### Fixing Bath Concentrations

Colour Process	Dilution Tank Filling Conc. + Water	Replenisher Conc. + Water
70	1 + 5	1 + 4
44	1 + 7	1 + 6
<u>BW Process</u>		
Film	1 + 6	1 + 5
PE & Baryta Base Papers	1 + 6	1 + 5

All processes for which FX-Universal is used can be recycled together after electrolytic silver recovery, and after FX-J Rejuvenator has been added.

Note: As the Agfachrome Process 44 and Kodak E6 process do not feature washing between the bleaching and fixing baths, this fixing bath must not be rejuvenated together with the Fixing baths of the other processes. Otherwise, it will be contaminated by carryover of the bleaching bath and cannot be used for black and white materials.

SAFETY PRECAUTIONS : IF CONTACT WITH SKIN OR EYES OCCURS, RINSE THOROUGHLY WITH WATER. IF SWALLOWED, RINSE OUT MOUTH AND GIVE PLENTY OF WATER TO DRINK (ONE SPOONFUL OF COMMON SALT TO A GLASS OF WATER). CONSULT A DOCTOR. CONTAINS THIOSULPHATE.

AGFA-GEVAERT LIMITED,  
MILWAUDDING, VIC., 3131

MADE IN  
GERMANY

LA010 V002 LOG/F 38