

ADOX MCC 110

Test Date: 01/05/16
Curves: #58 filter, #47, No filter
Printing: contact
Development: Dektol, 1+2, 69°F, 2.5min
Toner: none
Drying Method: air
Notes: H2O stop bath for 1min. 2 min in TF3

Step	Step Tablet	#58 filter	#47	No filter
1	0.04	1.43	2.03	2.02
2	0.18	1.34	2.02	2.01
3	0.33	1.23	2.00	2.01
4	0.49	1.10	1.97	2.01
5	0.65	0.96	1.90	2.01
6	0.79	0.83	1.78	2.00
7	0.93	0.71	1.61	2.00
8	1.09	0.58	1.32	1.96
9	1.24	0.46	1.02	1.88
10	1.39	0.37	0.74	1.77
11	1.54	0.29	0.50	1.61
12	1.71	0.22	0.29	1.31
13	1.86	0.17	0.19	1.05
14	2.01	0.14	0.13	0.80
15	2.17	0.11	0.10	0.56
16	2.34	0.10	0.09	0.37
17	2.50	0.09	0.08	0.24
18	2.65	0.09	0.07	0.16
19	2.80	0.09	0.07	0.12
20	2.97	0.07	0.07	0.10
21	3.14	0.07	0.07	0.10